




# Trafficote™ 105 Self-Leveling Slurry

**General Polymers TRAFFICOTE #105 FLOORING SYSTEM** is a high build (1/16" - 1/8"), chemical resistant protective self-leveling system which utilizes high solids binder resins and selected aggregates to produce a resin-rich material that is easily applied with a v-notched trowel or squeegee.



## Advantages

- Acceptable for use in USDA inspected facilities
- Seamless, easy-to-clean surface
- Durable, wear and slip resistant
- Chemical and stain resistant
- Available with an antimicrobial agent

## Uses

- Manufacturing areas
- Animal Care
- Clean rooms
- Pharmaceuticals
- Locker rooms and restrooms
- Packaging and storage areas

## Typical Physical Properties

Color	Standard Colors Computerized custom color matching available upon request
Hardness @ 24 hours, Shore D	70/65
ASTM D 2240	
Compressive Strength	12,000 psi
ASTM C 579	
Tensile Strength	
ASTM C 307	1,900 psi
ASTM D 638	6,000 psi
Abrasion Resistance	90-100 mgs lost
ASTM D 4060, CS-17 Wheel, 1,000 cycles	
Flexural Strength	
ASTM C 580	4,000 psi
Adhesion	300 psi
ACI 503R	concrete failure
Impact Resistance	Withstands 16 ft lbs
MIL-D-3134, Sec.4.7.3	without cracking, delamination or chipping
Flammability	Self-Extinguishing over concrete
Resistance to Elevated Temperatures	No slip or flow at required temperature of 158°F
MIL-D-3134J	

## Installation

General Polymers materials shall only be installed by approved contractors. The following information is to be used as a guideline for the installation of the **TRAFFICOTE #105 FLOORING SYSTEM**. Contact the Technical Service Department for assistance prior to application.

## Surface Preparation – General

General Polymers systems can be applied to a variety of substrates, if the substrate is properly prepared. Preparation of surfaces other than concrete will depend on the type of substrate, such as wood, concrete block, quarry tile, etc. Should there be any questions regarding a specific substrate or condition, please contact the Technical Service Department prior to starting the project. Refer to Surface Preparation (Form G-1).

## Surface Preparation – Concrete

Concrete surfaces shall be abrasive blasted to remove all surface contaminants and laitance. The prepared concrete shall have a surface profile depending upon system selected. Refer to Form G-1.

After initial preparation has occurred, inspect the concrete for bug holes, voids, fins and other imperfections. Protrusions shall be ground smooth while voids shall be filled with a system compatible filler. For recommendations, consult the Technical Service Department.

## Temperature

Throughout the application process, substrate temperature should be 50°F – 90°F. Substrate temperature must be at least 5°F above the dew point. Applications on concrete substrate should occur while temperature is falling to lessen offgassing. The material should not be applied in direct sunlight, if possible. Protect material from freezing prior to installation.

## Application Information – Surface Prep Profile CSP 4-6

VOC MIXED		MATERIAL	MIX RATIO	THEORETICAL COVERAGE PER COAT CONCRETE	PACKAGING
<50 g/L	<b>Primer</b>	3579	2:1	250 sq. ft./gal	3 or 15 gals
<50 g/L 0 0	<b>Slurry 1/16” Smooth</b>	3561 5350 5310	4:1	56 sq. ft./ 1.25 gal 6 lbs / 1.25 gal 13 lbs / 1.25 gal	1.25- 250 gals 50 lbs. 50 lbs
<50 g/L 0 0	<b>Slurry 1/8” Non-Skid</b>	3561 5350 5310	4:1	56 sq. ft./ 1.25 gal 6 lbs / 1.25 gal 13 lbs / 1.25 gal	1.25- 250 gals 50 lbs. 50 lbs
0	<b>Broadcast</b>	5310	To Excess	0.6 - 0.8 lbs. / sq. ft.	50 lbs
<100 g/L	<b>Grout Coat -1/8”</b>	3745 pre-measured units	2:1	100-150 sq. ft./gal	1,5, or 15 gals
<100 g/L	<b>Topcoat</b>	3745 pre-measured units	2:1	100-150 sq. ft./gal	1,5, or 15 gals

**Different optional seal coats – Consult individual Technical Data Sheets for mixing and application instructions.**

3505 Stipple Epoxy Floor Coating  
4638 HS Polyurethane Floor Enamel

## Primer

### Mixing and Application

1. Premix 3579A (resin) using a low speed drill and Jiffy blade. Mix for one minute and until uniform, exercising caution not to introduce air into the material.
2. Add 2 parts 3579A (resin) to 1 part 3579B (hardener) by volume. Mix with low speed drill and Jiffy blade for three minutes and until uniform. To insure proper system cure and performance, strictly follow mix ratio recommendations.
3. 3579 may be applied via spray, roller or brush. Apply 5-8 mils, evenly, with no puddles. Coverage will vary depending upon porosity of the substrate and surface texture.
4. Wait until primer is tacky (usually 1 hour minimum), before applying the slurry. If primer is not going to be topped within open time, broadcast silica sand into resin lightly but uniformly and allow to cure overnight.

## Slurry - 1/16" Smooth

### Mixing and Application

1. Premix 3561A (resin) using a low speed drill and Jiffy blade. Mix for one minute and until uniform, exercising caution not to whip air into the material.
2. Add 1 gallon 3561A (resin) to 1 quart 3561B (hardener). Mix with low speed drill and Jiffy blade for three minutes and until uniform. Slowly add up to 6 lbs 5350 Trafficote Filler and up to 13 lbs. of 5310 Dry Silica per 1.25 gallons of mixed epoxy. Mix with low speed drill and Jiffy blade for three minutes and until uniform and no lumps remain.

#### NOTE:

- 1 gallon of unpacked 5350 is approximately 6 lbs.
- 1 gallon of unpacked 5310 is approximately 13 lbs.

3. Immediately pour the mixed material onto the substrate and pull out using a 1/4" v-notched trowel or 1/4" red rubber squeegee.
4. Allow material to self-level 10-15 minutes, the surface should be lightly backrolled with a looped roller to help smooth. Use a spiny roller to aid in the release of air.
5. Allow to cure (Cure times vary depending on environmental conditions).

## Slurry - 1/8" Non-Skid

### Mixing and Application

1. Premix 3561A ((resin) using a low speed drill and Jiffy blade. Mix for one minute and until uniform, exercising caution not to whip air into the material.
2. Add 1 gallon 3561A (resin) to 1 quart 3561B (hardener). Mix with low speed drill and Jiffy blade for three minutes and until uniform. Add 6 lbs. of 5350 Trafficote filler and 13 lbs. of 5310 Dry Silica Sand to 1.25 gallons of mixed epoxy and mix thoroughly using a low speed drill and Jiffy blade for three minutes and until uniform and no lumps remain.
3. Immediately pour the mixed material onto the substrate and pull out using a 1/4" v-notched trowel or 1/4" red rubber squeegee.
4. Allow material to self-level 10-15 minutes, the surface should be lightly backrolled with a looped roller to help smooth. Use a spiny roller to aid in the release of air. Begin evenly seeding 5310 Dry Silica Sand (20-40 mesh or other approved non-skid aggregate) into the wet resin much the same as grass seed is spread. Sand may be spread by hand or mechanical blower but should be broadcast in such a way that the sand falls lightly into the resin without causing the resin to move. Continue broadcasting to excess until the floor appears completely dry.

5. Allow to cure, sweep off excess sand with a clean, stiff bristled broom. Clean sand can be saved for future use. All imperfections such as high spots should be smoothed before the application of the grout coat.

NOTE: Dry Silica Sand distribution is critical to the success if the application. The floors finished appearance depends on the manner in which the sand has been applied. In grass seed like fashion, allow the sand to fall after being thrown upward and out. DO NOT THROW DOWNWARD AT A SHARP ANGLE USING FORCE.

NOTE: Trafficote may be placed into service after the base slurry/broadcast has cured. Grout coats and topcoats can be applied based upon desired texture and finish

## Grout Coat for 1/8" Non-Skid

### Mixing and Application

1. Premix 3745A (resin) using a low speed drill and Jiffy blade. Mix for one minute and until uniform, exercising caution not to introduce air into the material.
2. Add 2 parts 3745A (resin) to 1 part 3745B (hardener) by volume. Mix with low speed drill and Jiffy blade for three minutes and until uniform. To insure proper system cure and performance, strictly follow mix ratio recommendations.
3. Apply 3745 using a flat trowel or flat squeegee and backroll with a 1/4" nap roller at a spread rate of 100-150 sq. ft. per gallon, evenly, with no puddles making sure of uniform coverage. Take care not to puddle materials and insure even coverage.
4. Allow to cure 24 hours minimum before applying seal coat.

## Topcoat

### Mixing and Application

1. Premix 3745A (resin) using a low speed drill and Jiffy blade. Mix for one minute and until uniform, exercising caution not to introduce air into the material.
2. Add 2 parts 3745A (resin) to 1 part 3745B (hardener) by volume. Mix with low speed drill and Jiffy blade for three minutes and until uniform. To insure proper system cure and performance, strictly follow mix ratio recommendations.
3. Apply 3745 using a flat trowel or flat squeegee and backroll with a 1/4" nap roller at a spread rate of 100-150 sq. ft. per gallon, evenly, with no puddles making sure of uniform coverage. Take care not to puddle materials and insure even coverage.
4. Allow to cure 24 hours minimum before opening to traffic. Epoxy materials will appear to be cured and "dry to touch" prior to full chemical cross linking. Allow epoxy to cure for 2-3 days prior to exposure to water or other chemicals for best performance.

### Different optional seal coats — Consult individual Technical Data Sheets for mixing and application instructions.

3505 Stipple Epoxy Floor Coating  
4638 HS Polyurethane Floor Enamel

## Cleanup

Clean up mixing and application equipment immediately after use. Use toluene or xylene. Observe all fire and health precautions when handling or storing solvents.

## Safety

Refer to the MSDS sheet before use. federal, state, local and particular plant safety guidelines must be followed during the handling and installation and cure of these materials.

Safe and proper disposal of excess materials shall be done in accordance with applicable federal, state, and local codes.

## Material Storage

Store materials in a temperature controlled environment (50°F - 90°F) (10°C - 32°C), and out of direct sunlight. Keep resins, hardeners, and solvents separated from each other and away from sources of ignition. Shelf life of material will vary, check individual product data sheet.

## Maintenance

Occasional inspection of the installed material and spot repair can prolong system life. For specific information, contact the Technical Service Department.

## Shipping

- Destinations East of the Rocky Mountains are shipped F.O.B. Cincinnati, Ohio.
- Destinations West of the Rocky Mountains are shipped F.O.B. Victorville, California.

For specific information relating to international shipments, contact your local sales representative.

## Disclaimer

The information and recommendations set forth in this document are based upon tests conducted by or on behalf of The Sherwin-Williams Company. Such information and recommendations set forth herein are subject to change and pertain to the product(s) offered at the time of publication. Published technical data and instructions are subject to change without notice.

Consult [www.generalpolymers.com](http://www.generalpolymers.com) to obtain the most recent Product Data information and Application instructions.

## Warranty

The Sherwin-Williams Company warrants our products to be free of manufacturing defects in accord with applicable Sherwin-Williams quality control procedures. Liability for products proven defective, if any, is limited to replacement of the defective product or the refund of the purchase price paid for the defective product as determined by Sherwin-Williams, NO OTHER WARRANTY OR GUARANTEE OF ANY KIND IS MADE BY SHERWIN-WILLIAMS, EXPRESSED OR IMPLIED, STATUTORY, BY OPERATION OF LAW OR OTHERWISE, INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.



**To learn more, visit us at**

[www.sherwin-williams.com/protective](http://www.sherwin-williams.com/protective)  
or call 1-800-524-5979  
to have a representative contact you.

©2014 The Sherwin-Williams Company  
Protective & Marine Coatings 09/14